



INSTALLATION INSTRUCTIONS FOR SHEET GOODS

Tool Requirement:

1. Tape measure
2. Utility knife
3. Straight edge
4. Caulk line
5. 150 lb. three section roller
6. Multi Purpose adhesive

Guidelines:

1. Roll goods should be removed from shipping packaging, unrolled to lay flat and acclimate in installation area whenever possible. Reverse rolling the product often times aids in relaxing the roll memory of the product. Floor covering and adhesive must be at room temperature or 65°F for 48 hours prior to and after installation.
2. Floor must be sound and should be stripped of all waxes and floor finishes, and should be clean, dry and free of debris prior to installation. Use quality latex/Portland cement based type-patching compound to fill or level any irregular areas in the sub floor. Never sand resilient floors, they may contain asbestos.
3. Important! Be sure to install with material in the same pile direction. Inspect all rolls for damage prior to beginning installation. Report damage before cutting or installing.

Installation Instructions:

1. Determine centerline in both North – South, and East – West directions of area to be covered in roll goods. Then determine roll seams lines, snap caulk lines for alignment of roll edges.
2. Spread adhesive with a 1/8" x 1/16" V-notched trowel. Apply only as much adhesive that can be installed within 30 minutes
3. Begin at the roll seam line closest to the center and work to the outside. Unroll product from center out to ends. Press roll goods firmly into adhesive and butt seams tightly, Note: seam sealer is not required. A “serpentine cut” can be used to completely hide seams. Trim to fit on outside edges with a utility knife that has a sharp blade.
4. Roll installed roll goods in both directions with a 150 lb three section roller
5. Inspect to insure there are no gaps and product is flat and securely in place.

Questions, please give us a call for assistance 1-866-CvG-Mats