



# FRONTRUNNER PLUS SB

SOLID-BACKED GRID MATTING SYSTEMS

*All the benefits of Frontrunner Plus with an added solid backed design, to keep your space clean from debris.*

When used in conjunction with Frontrunner Plus, which additionally removes moisture, the system provides permanent entrance protection that is durable and certified slip resistant.

- Frontrunner Plus SB is made from a hard-wearing, flexible PVC
- Wheeled-traffic friendly including shopping trolleys
- Open grid design lets debris fall through



01. Black (Regular & LP) with Smoke 608 Carpet

# FRONTRUNNER PLUS SB

## SOLID-BACKED GRID MATTING SYSTEMS



### SUGGESTED USES

Indoor entryways or other high-traffic areas with no recessed matwell. Ideal for vestibules.

### SPECIFICATIONS

Grid Composition:	Flexible PVC
Overall Thickness:	0.315" (8mm)
Grid Thickness:	0.25" (6.5mm)
Total Carpet Thickness:	0.35" (9mm)
Carpet Pile Height:	0.27"   7mm
Carpet Pile Weight:	24.2 oz/sy
Total Carpet Weight:	126 oz/sy
Roll Widths:	3'3" available
Roll Lengths:	33' (standard)
LEED-NC	MR Credit 4   IEQ Credit 5

### LIMITED WARRANTY

2 years - Ask for warranty sheet for details

### TECHNICAL SPECIFICATIONS (GRID)

Friction ASTM C1028:	0.54 (Wet), 0.66 (Dry)	DIN 51130: R11, V10
Fire Resistance (ASTM E648):		Class 1
Flame Retardant Grade (EN ISO 13501-1:2007-CFL):		S1
Abrasion (ASTM D3884):	0.4%/ 1,000 cycles	
UV Resistance (BS EN 607):	Δ E 1.02 (Uncolored Material)	
PVC material:	BS EN 607 = Delta E 1.02	

### TECHNICAL SPECIFICATIONS (CARPET)

Fiber:	100% BCF Nylon (Tufted)
Backing:	Colback non-woven polyester (Primary) Comfort vinyl (Secondary)
Carpet Attachment Method:	Ultrasonic Welded
Electrostatic Propensity (DIN EN 1815):	2kV
Smoke Density (ASTM E662-13):	Passes
Surface Flammability (FF 1-70/ASTM D2859):	Passes

### ENVIRONMENT

van Gelder Inc. does not use any substances currently included in the SVHC (Substances of Very High Concern) list under REACH (Registration, Evaluation, Authorization and Restriction of Chemical substances) in any matting products. All PVC grid products are 100% recyclable.

### THERMAL

Functional -23C +60C (slight size variation may occur at temperature extremes).

### MAINTENANCE

DAILY: Vacuum with an industrial cleaner. Should stones, salt particles or other solid matter become embedded between the surface ribs, remove using a blunt instrument (screwdriver) or similar device. In addition to daily routine above, its important to

remove chewing gum deposits and stains as they appear.

WEEKLY: Complete daily cleaning routine, then clean top surface using cylindrical brush machine. Initially work in direction of top ribs then across the ribs to complete cleaning. If a cylindrical brush machine is not available equally good results can be achieved using a high-pressure water extraction process.

RECESSED WELL CLEANING (AS NEEDED): Carefully lift and remove each section of grid matting one at a time. Once all of the Frontrunner Plus SB sections have been removed vacuum/ sweep the recess thoroughly, ensuring to pick up all stones or grit particles. Replace the matting sections as originally laid working from the edges to the center of the installation. When installing the sections at the edge of the frame, be sure to slide them under the frame lips.

### INSTALLATION

PREPARATION: Ensure recessed well is at a depth of 10mm from the finished floor level. It should have a level and sound base, free from any obstructions. Before commencing installation, visually check the recess and remove any lumps or ridges in the base that may be present. Vacuum and/or sweep recess.

It is recommended that the entrance flooring system be installed as one of the final jobs to avoid damage associated with general building works. Unpack and inspect all materials to ensure they are free from transport damage. Check all components and tools required are available. Unroll/unpack the sections of matting and lay in a clean dry protected area to acclimatise and relax. Depending on duration of storage and ambient temperature, this process may take up to 24 hours. A heat gun can be used to aid relaxation of matting. When handling the rolls or large panels of matting at any time during the installation, avoid dragging or rough handling that may cause stretching or distortion.

TOOLS REQUIRED: Aluminum sections (5 types, supplied as required); screws, screw anchors and shears for trimming mat; a powered drill with size 5.5mm masonry drill bit, hacksaw, utility knife and straight edge; a hot air gun may facilitate installation in cold ambient temperatures.

Cut matting using a utility knife and a straight edge. In cold ambient temperatures warm matting with hot air gun to facilitate cutting. NOTE: Due to the elastic nature of the product, it is important to avoid rough handling during installation.

For more information on how to install Frontrunner Plus SB in your space, contact your van Gelder Inc. sales representative.

### YOUR AUTHORIZED SALES REPRESENTATIVE:

vG\_FrontrunnerPlus\_SB\_112822



van Gelder, Inc.  
www.vangelder-inc.com  
+1 706 602 4186

### EXPERIENCE IT FOR YOURSELF

Talk with your sales representative or request samples at [samples@vangelder-inc.com](mailto:samples@vangelder-inc.com)